



NOTE:

1. SET MAILBOX POST SO FACE OF MAILBOX IS AT BACK EDGE OF SHOULDER OR 8 INCHES BACK FROM FACE OF CURB FOR STREETS WITH CURBING.
2. CUT NOTCHES IN POST AND TOP RAIL TO FORM CROSS HALVING JOINT AND BOLT 2 PIECES TOGETHER.

TOWN OF BRUNSWICK
 APPROVED MAILBOX DESIGN
 BRUNSWICK PUBLIC WORKS DEPARTMENT
 SCALE: 1/2" = 1'-0"